

# Quick Start Guide

## INSTEON® Dimmer Module

Models: 2632-422, 2632-432, 2632-442, 2632-522



2632-442  
(UK)



2632-522  
(Aus/NZ)



2632-432  
(Germany)



2632-422  
(France)


### Install INSTEON Dimmer Module

- 1) Turn on lamp
- 2) Unplug lamp and plug it into Dimmer Module receptacle
- 3) Plug Dimmer Module into unswitched wall outlet

*Lamp will turn on and Dimmer Module LED will turn on green*

### Make Dimmer Module a Responder

- 1) Press and hold controller button until it beeps  
*Controller LED will start blinking*
- 2) Press and hold Dimmer Module paddle top or bottom to adjust load to desired brightness (or off) when scene is activated
- 3) Press and hold Dimmer Module set button until it double-beeps  
*Controller will double-beep and its LED will stop blinking*
- 4) Test link by tapping controller button on and off  
*Connected load will return to the state set in step #2*



### Assign an X-10 Address

- 1) Press and hold Dimmer Module set button until it beeps  
*Dimmer Module LED will start blinking green*
- 2) Send the X10 address 3 times (with or without commands)  
*Example: A1-A1-A1-AON or A1-AON-A1-AON-A1-AON*  
*Dimmer Module will double-beep and its LED will stop blinking*
- 3) Test by sending X10 on and off commands  
*Load will turn on and off*

### Owner's Manual and Tech Support

Visit: <http://www.insteon.com/support> for complete manual, online tech support and updated product documents.  
Call: INSTEON Support Line at 866-243-8022